this warning period, the remote operator shall broadcast at least twice, via marine radio, that: "The drawspan of the EJ&E Railroad bridge will be lowered in one minute." A siren on the bridge sounds for 20 seconds, to warn anyone on or under the bridge that the drawspan will be lowered.

- (5) If a vessel is approaching the bridge upbound or, departing the Lockport Lock and Dam at mile 291.1, downbound, with intentions of passing through the drawspan, they shall respond to the remote bridge operators' marine radio broadcast, or initiate radio contact, indicating their proximity to the bridge and requesting an opening of the drawspan or that the drawspan remain open until the vessel passes. If any approaching vessel is detected or if a radiotelephone response is received, the remote operator shall not close the drawspan until the vessel or vessels have cleared the bridge.
- (6) At the end of the one minute warning period, if no river traffic is approaching or under the drawspan, the remote bridge operator may begin lowering the drawspan. Navigation lights located at the center of the drawspan change from green to red when the drawspan is not in the fully open to navigation position. The drawspan takes approximately 90 seconds to lower.
- (7) If the presence of a vessel or other obstruction is discovered approaching or under the drawspan, during the lowering sequence, before the drawspan is fully lowered and locked, the drawspan shall be stopped and raised to the fully open position. When the vessel or obstruction has cleared the drawspan, the remote operator shall confirm that the channel is clear and reinitiate the one minute warning cycle before lowering the drawspan.
- (8) If no marine traffic is present the drawspan may be lowered and seated. When the drawspan is lowered and locked in the closed to navigation position, the remote bridge operator periodically broadcasts, via marine radio, that: "The drawspan of the EJ&E Railroad bridge is closed to navigation."
- (9) Failure of the radar system, radio telephone system, infrared boat detectors or electronic motion sensors shall

prevent lowering the drawspan from the remote location.

(10) when rail traffic has cleared the bridge, the remote bridge operator shall raise the drawspan to the fully open to navigation position. When the drawspan is raised and in the fully open to navigation position, the remote bridge operator broadcasts, at least twice, via marine radio, that: "The drawspan of the EJ&E Railroad bridge is open to navigation." The center drawspan navigation lights change from red to green when the drawspan is fully open to navigation.

[CGD 82–025, 49 FR 17452, Apr. 24, 1984, as amended by CGD02 93–036, 59 FR 33677, June 30, 1994; USCG–1998–3799, 63 FR 3557, June 30, 1998; USCG–1999–5832, 64 FR 34712, June 29, 1999; CGD08–99–014, 64 FR 61520, Nov. 12, 1999]

§117.397 Wabash River.

The draws of each bridge across the Wabash River shall open on signal if at least 72 hours notice is given.

Indiana

§117.401 Trail Creek.

- (a) The draw of the Franklin Street bridge, mile 0.5 at Michigan City, shall be operated as follows:
- (1) From March 16 through November 30, the draw shall open on signal; except from 6:15 a.m. to 11:15 p.m., Monday through Sunday, the draw need open only from three minutes before to three minutes after the quarter-hour and three-quarter hour.
- (2) From December 1 through March 15, the draw shall open on signal if at least 12-hours advance notice is provided prior to intended time of passage.
- (b) The draw of the Amtrak bridge, mile 0.9 at Michigan City, shall open on signal; except, from December 1 through March 15, the bridge shall open on signal if at least 12-hours advance notice is provided prior to intended time of passage.
- (c) Public vessels of the United States, state or local vessels used for public safety, vessels in distress, and vessels seeking shelter from severe weather shall be passed through the draws of each bridge as soon as possible.

[CGD09-01-001, 66 FR 27867, May 21, 2001]